Particle Accelerators Their Hazards and the Perception of Safety

OVERVIEW AND LESSONS LEARNED



Kelly Mahoney, Engineering Manager for Safety Systems
TJNAF (Jefferson Lab)
mahoney@jlab.org




Particle Accelerators


- Medical Therapy, Surgery, Imagery, Isotope Production
- Industrial Material Fabrication, Sterilization, Inspection
- Material Science Probe Atomic Structure, Build Materials at Atomic scale, Waste Treatment
- Fundamental Research Study of Constituents of Matter, Energy, and Binding Forces

Resolution of a probe is inversely proportional to the energy of the probe – Smaller resolution requires higher energy.






MIT Bates





Large Hadron Collider Geneva, Switzerland




Fusion Facilities


94 PW Class Lasers
 Focus on a 1mm Bead



National Ignition Facility



Next Generation





Jefferson Lab

- Continuous Electron Beam Accelerator Facility (CEBAF)
 - 6 GeV, 1MW electron Accelerator
 - Superconducting Accelerators @ 1.8 Kelvin, 30,000 ll He
 - Three Experimental Endstations, Magnetic Fields > 15 T
 - 12GeV upgrade under way
- Free Electron Laser
 - 20 kW IR through 2 kW UV
 - Energy Recovery Recirculating Linac




JLab Facility Large Scale Hazards

Hazard Area	Prompt Ionizing Radiation	RF non- Ionizing Radiation	Laser Non-ionizing Radiation	Electrocution	Oxygen Deficiency
CEBAF	✓	✓	✓	✓	✓
FEL	✓	✓	✓	✓	✓
Injector Test Cave	✓		✓	✓	
Cryomodule Test Area	✓	✓			✓
Vertical Test Area	✓	✓			



Beam Loss

• 1MW beam can burn through 1/8" steel in 50 uS



JLab Safety Systems

- Personnel Safety Systems
 - Access Controls
 - Critical Devices
 - Equipment Interlocks
 - Audio and Visual Warnings
 - Oxygen Deficiency Monitoring
- Machine Protection Systems
 - Beam Loss Monitoring
 - Fast Shutdown
- Safety Envelope Monitoring




CEBAF Personnel Safety Systems

- Access Controls and Interlocks
- Radiation Monitoring
- ODH Monitoring
- 7 Operational Segments
 - Separate, Redundant Safety Systems
 - Can Operate Independently
 - 3,000 total control parameters





100 MV Cryomodule




Production/R&D Facilities


- Machinery
- Acid Processing
- Prompt Ionizing Radiation
- Lasers













Context? Constraints?

Management Process
Systems Engineering Process
Controls Engineering Process
Software Engineering
Process
Assurance Process



Oxygen Deficiency

- He can inert tunnel to $< 6\% O_2$
- Oxygen Monitors in Tunnel
- Penetrations sealed for Radiation and Fire Safety



Lesson Learned: Fluorescent Lights Extinguish During Release. Lesson Learned: Have procedures in place for times when the ODH system is off-line.



JLab Safety Systems Management

- Systems Engineering Process
 - Systems Assurance
 - Software Assurance
 - Cyber Security Assurance
- Based on IEEE/IEC 15288/12207
- Borrow heavily from Aerospace and Chemical Industries

Lesson Learned: Start with an overall systems engineering process to set the context for managing safety systems




Early Decisions

- Facility Segmentation
 - Identify fail-safe methods for stopping beam transport
- Civil Construction Requirements
 - Access Portals
 - Segmentation Features
 - Movable Shielding
 - Life Safety Code

Lesson Learned:
Basic Safety System design decisions may impact facility operations and civil design.




Human Factors






Requirements Flow-Down



CEBAF Safety Functions

Function ID	Safety Function	Required SIL
SF1	Prevent beam transport from exclusion to occupied areas	3
SF2	Shut off interlocked devices when physical barriers between personnel and hazards are unsecured.	2
SF3	Shut off interlocked devices upon activation of an ESTOP	2
SF4	Shut off interlocked devices in support of administrative access to a secure beam enclosure.	2
SF5	Support search and secure operations prior to facility operations.	2
SF6	Inhibit operation of radiation generating devices when a high radiation dose rate associated with the device is detected in an occupied area	1
SF7	Deter unauthorized entry to exclusion areas	1
SF8	Provide visual indications of unsecured safe, secure safe, and unsafe radiological enclosure status.	1
SF9	Provide audible warnings of pending unsafe status of a beam enclosure	1
SF10	Activate audible and visual alarms when the indicated oxygen level in monitored areas drops below 19.5% by volume.	1

Requirements



Does not adequately capture constraints



Current Concerns

- Controls Cyber Security
 - Greatest concern is with engineering development PCs
 - Updating to meet ISA S99, NIST SP800-82
 - Safety Systems Cyber Security Assurance Program
 - Consulting with U.S. ICS-CERT
- Threat at multiple vectors
- Vulnerable components are engineering development workstations, display systems
- Highlights malicious intent as threat
- Active (?) degradation over time
 - APT



Conclusions

- Scale of Hazards are Large and Complex
- Operators are an integral part of the system
- Hazards evolve with facility age and mission
- Disciplines of Systems, Software, Safety, Security overlap
 - Why not integrate them in to one discipline



Thank You

Questions?

